
Officesto**Go**

OTGMA2

ASSEMBLY INSTRUCTIONS




LOADING CAPACITY 2.2 - 17.6 lbs per monitor

SCREEN SIZE 17" - 29"


Parts List

Officesto**Go**

Components




Parts in the Grommet Installation Parts Bag (Used for grommet installation)





EXPLODED VIEW


Officesto**Go**



STEP 1 - Select a Base Installation Option




Officesto**Go**



Option 1b - Grommet Method

1b-1


Loosen the screws to remove the clamp base.



Officesto**Go**


1b-2

Connect the grommet base plate to the pole.




1b-3

Center and tighten the long screw through desk as below displays.




STEP 2 - Arm Installation

Officesto**Go**



2-2

Release the lever when desired height is reached.




2-3

Place top cap on the top of the pole and push down to secure.



STEP 3 - VESA Plate Installation

Officesto**Go**




STEP 4 - Monitor Installation

Officesto**Go**




Slide in and lock-in.




NOTE

NOTE: Before removing the monitor, ensure the **UP** arrow towards upward.



NOTE

Press down lever on the VESA plate and carefully lift the monitor upwards.




OTGMA2 ASSEMBLY INSTRUCTIONS


NOTE

Tilt adjustment to hold heavier monitor.


Officesto**Go**



STEP 5 - Cable Management



Officesto**Go**



NOTE

For better adjustment, please hold the monitor during the up/down adjustment process.

